


Lightboard

Overview



Service Lighting Scenes

- 1- **Preservice** - All House Lights On
- 2- **Welcome** - Half House Lights On & Pulpit Lights On
- 3- **Worship** - Stage Lights On, Wall Lights On, Pulpit Lights On
- 4- **Bumper Video** - Half House Lights On & Pulpit Lights Off
- 5- **Sermon/Announcements** - All House Lights On & Pulpit Lights On
- 6- **Closing Worship** - Stage Lights On, Wall Lights On, Pulpit Lights On, & Back House Lights On
- 7- **End of Service** - All House Lights On
- 8- **Blackout** - All Lights Off



How to save a scene

Step 1: Adjust Faders to the desired lighting

Step 2: Press and hold the “Program” button for 3 seconds

Step 3: Press the “Mid/Add” button

Step 4: Press the desired “Scene” button

Step 5: Press and hold “Program” until the house lights turn off


Step 6: Press the “Blackout” button to turn all lights back on

Repeat for every scene



HOUSE LIGHTS

Lightboard Faders 1 - 12
(DMX Channels 1-12)



unsure what channels 1-3 operate as of April 2026